


ASSEMBLY INSTRUCTIONS

CR-87711 - CR-87148 / STOOLS


HARDWARE:

| Item | Descri | ption | QTY |
|------|---------------|--------------------|-----|
| H1 | Long Bolt | 1/4 "*3" | 4 |
| H2 | Short Bolt | 1/4"*1-3/4" | 1 |
| Н3 | Medium Bolt | 1/4"*2-1/4" | 4 |
| H4 | Spring Washer | C 1/4"*1.2mm | 9 |
| Н5 | Washer | ①1/4"*19*1.2mm | 9 |
| Н6 | Allen Key | ✓ 4mm | 1 |
| H7 | Screw | #8*1/2 | 6 |



PARTS:

| ltem | Description | QTY |
|------|------------------------|-----|
| Α | Seat | 1 |
| В | Front Legs | 2 |
| С | Front Stretcher | 1 |
| D | Back | 1 |
| ER | Right Facing Stretcher | 1 |
| EL | Left Facing Stretcher | 1 |



ATTENTION:

SINCE HARDWOOD AND VENEER ARE USED IN THIS FURNITURE, THERE MAY BE VARIATIONS IN COLOR, SHADE, AND PATTERN. WOOD IS A NATURAL MATERIAL SO NO TWO PIECES ARE EXACTLY ALIKE. AS A RESULT, EACH PIECE TAKES THE STAIN DIFFERENTLY. IT IS THIS VARIATION THAT MAKES WOOD AND VENEER SO BEAUTIFUL.

TO CLEAN: DUST WITH A SOFT, CLEAN CLOTH AND USE A QUALITY FURNITURE POLISH. DO NOT USE ANY CLEANERS CONTAINING ALCOHOL, ACETONES, OR OTHER STRONG SOLVENTS.